


MY CHILD[®]

Graze
3-in-1 Highchair



IMPORTANT!
KEEP FOR FUTURE REFERENCE

INSTRUCTIONS:

Conforms to EN14988-1: 2006+A1:2012 / EN16120: 2012+A1:2014

Suitable for children who can sit up unaided, aged approximately 6-36 months but not exceeding 15kg/33lbs. Your child's safety may be affected if you do not follow these instructions.

Contents

Care and maintenance	2
Safety Instructions	3-4
Your 3 year warranty	4
Welcome	4
Parts checklist	5
Assembling the booster seat	6-7
Assembling the stool	8-9
Assembling the highchair	9
The tray	10
Securing your child in the harness	11
Using the booster seat	11-13
After use	14-15

Care and maintenance

- The highchair can be cleaned by using a sponge with warm water and a mild detergent.
- The tray can be washed under running water with mild cleaning liquids.
- Avoid soiling the strap buckle to ensure it works correctly. If the buckle gets dirty, it can be soaked and rinsed in warm water.
- The 5-point harness can be removed and hand washed at 30°C using a mild detergent. Do NOT tumble dry. Air dry only.
- A mild disinfectant can be used if desired. Stubborn marks may be removed with a non-abrasive cleaner.
- The highchair must be dried thoroughly before using or storing.
- Never clean with abrasive, ammonia based, bleach based or spirit type cleaners.
- To prolong the life of your highchair, keep it clean and do not leave it in direct sunlight for extended periods of time.
- Check your highchair for loose screws, worn parts, torn material or stitching on a regular basis, replace or repair parts as necessary.
- Do not use the highchair if any part is broken, torn or missing.

Safety instructions

We know that safety is of utmost concern for parents and carers of children. Whilst this product has been developed to all of the relevant safety standards, we need your help to maintain that level of safety and minimise the risk of a baby using this product being harmed. Your baby should never be left alone in the highchair and all harmful objects should be kept out of your child's reach.

Warning: Do not use the highchair until the child can sit up unaided.

Warning: Do not use the highchair unless all components are correctly fitted and adjusted. Your child's safety is your responsibility.

Warning: To avoid injury keep your child away when folding and unfolding this product. Do not let your child play with this product.

Warning: Do not leave the child unattended in the highchair, direct adult supervision is required at all times.

- Always keep your child in view while in the highchair.
- Never allow your highchair to be used as a toy.
- Ensure that the locks and catches on the product are not obstructed at any time during use.
- Ensure the safety harness is fastened and correctly adjusted at all times.
- When making adjustments to the highchair, ensure that you and your child's body, fingers and toes are clear of any moving parts on the highchair, otherwise they may be injured.
- Do not use near stairs or steps.
- Ensure the highchair is used on a secure and level surface.
- Do not elevate the highchair on any structure or table.
- Position the highchair away from solid structures and benches to avoid injuries caused by falls and access to dangerous items.
- Reduce the risk of injury, position the highchair away from furniture, walls, hot surfaces and liquids, window covering cords and electrical cords and when the highchair is not being used at a table with the highchair tray removed.
- The tray is not designed to hold the child in the chair.
- Tray maximum load weight: 5kgs.
- Be aware of the risks of open fires and other such sources of strong heat, such as electrical bar fires, gas fires etc. in the vicinity of this highchair.
- Never carry the highchair with your baby in it.
- Periodically check for loose or damaged parts and **DO NOT** use if any part is broken, torn or missing.
- Only use parts and accessories approved by the manufacturer. Others may render the highchair unsafe and will invalidate the warranty.
- This highchair is designed to hold 1 child.
- Accessory items may change the balance of the highchair and cause hazardous unstable Conditions.

Safety instructions (continued)

- Attach the booster seat to a stable chair with a seat back.
- When used as a chair mounted booster seat on a regular chair, the chair seat should be at least 20mm bigger than the booster seat on all sides, with exception of the back side.
- When used as a chair mounted booster seat on a regular chair; always use the chair attachment system and ensure it is correctly fitted before use.
- Always secure the booster seat on a regular chair using the bottom and back attachment straps.
- Never use the booster seat on a stool or bench that does not have a seat back.
- Ensure that the adult chair with the chair mounted booster seat is placed in a position where the child is not able to use its feet to push against the table or any other structure as this can cause the tip over of the adult chair supporting the chair mounted seat.

Your 3 year warranty

Whilst we make and test our products to the highest standards of durability there's always a small chance of a hiccup! Our promise is to repair, replace or refund a MyChild product that has an identified manufacturing defect from the date of purchase for a full 3 years thereafter at no extra cost.

However, you must register within 28 days of the date of purchase to receive the full 3 years guarantee!

To receive your full guarantee you can register your product by: visiting www.mychild.co.uk/warranty.html and complete the warranty form, or by telephone on 0161 335 2508.

Welcome

Thank you for purchasing the MyChild Graze 3-in-1 Highchair. Please read the instructions and warnings carefully before use to ensure safe and satisfactory operation of this product.

Your child's safety is your responsibility. If you have a query with this product or require replacement parts, please contact the MyChild Helpline on 0161 335 2508.


Lay out the parts on a soft level surface and compare to the part/fixings checklist below. Do not discard any packaging until you are sure that you have all the parts.

WARNING! Assembly by an adult. Keep away from children until fully assembled. Keep children clear during assembly as pack contains small parts which may present a choking hazard.



Parts checklist

Contained in your carton are:


Nº	Part	Qty
1	Food tray	1
2	Booster seat unit	1
3	Stool seat unit	1
4	Footrest	1
5	Upper leg tubing	4
6	Lower leg tubing	4
7	Tray insert	1




1




2



3




4



5




6




7

Assembling the booster seat




1. Removing the food tray:

Slightly pull both tabs (A) on each side of the tray outwards to release the food tray.



2. Removing the Stool seat unit:


Press both buttons (B) and lift the booster seat upwards to release the stool seat unit.



3. Fixing the backrest:


Lift the backrest (C) upwards until it is upright, then press the backrest downwards until it clicks into place.

Assembling the booster seat (continued)



3. Adjusting the backrest:


Lift the backrest upwards to release it (D). Tilt the backrest slightly backwards (E) and then press it back down into place (F), ensuring it clicks into position.



3. Attaching the tray:


Line up the tab holes on the tray with the mounting points on the seat. Push the tray down onto the mounting points, ensuring the tray clicks into place and that the tab holes on both sides of the tray are in the same position.

Assembling the stool



1. Assembling the footrest:


Take two lengths of upper leg tubing (A), and place them through the holes in the footrest (B).



2. Leg assembly:

Insert the four lengths of lower leg tubing (C) into the upper leg tubing ensuring the spring pins click into place.

Assembling the stool (continued)




3. Attaching the stool seat:

Push the assembled front legs (D) and rear legs (E) into the holes on the underside of the stool seat (F) ensuring the front legs (D) are at the front of the seat and that all spring pins click into place.

NOTE: The front of the seat has a small round raised area (G).




Assembling the highchair



Place the assembled booster seat (A) on to the stool (B) ensuring the booster seat locks on securely on both sides.

IMPORTANT! Lift the highchair by the booster seat to check it is connected properly.


The tray



1. Removing and attaching the tray insert:

To remove the tray insert, press tab (A) and lift the tray insert out.

To attach the tray insert push the two tabs (B) on the tray insert into the slots on the tray then push tab (C) into the slot at the front of the tray.




2. Storing the food tray:

The food tray can be stored on the back of the highchair by placing the plastic tab on the underside of the tray into the slot at the back of the chair


Securing your child in the harness

It is essential that the five-point harness is used at all times. When using the highchair or booster seat at a table ensure the child cannot push against the table or any other surface as this could result in the highchair or booster seat tipping over.



1. Releasing the 5-point harness:

Press the button (A) in the centre of the harness buckle and remove the clips.




2. Fastening the 5-point harness:

To secure your child in the harness, place the crotch strap between your child's legs and insert the harness clips into the buckle, making certain your child's fingers are clear. Adjust the sliders (B) on the waist and shoulder straps so that the harness fits snugly.


Using the booster seat

WARNING! To prevent serious injury or death from falls or sliding out:

- Attach to a stable chair with a seat back.
- When used on a regular chair, the chair seat should be at least 20mm bigger than the booster seat on all sides, with the exception of the back side.
- Always secure the product on a chair using the bottom and back attachment straps.
- Use the harness at all times.
- Never use this product on a stool or bench that does not have a seat back.
- Ensure that the adult chair with the booster seat is placed in a position where the child is not able to use its feet to push against the table or any other structure as this can cause the tip over of the adult chair supporting the chair mounted seat.
- Do not use the booster seat if any part is broken, torn or missing.




Using the booster seat (continued)




1. Accessing the booster straps:

Push down slightly on the plastic covers (A) and slide them backwards on each side of the booster seat to access the booster straps.




2. Preparing the booster straps:

Take out the booster straps from their storage space on both sides of the seat and undo the buckles.



3. Thread the straps through the slots:

On each side of the seat; take the length of booster strap that is on the inside of the storage space (B) and thread it into the slot at the back of the seat (C). The outside booster strap (D) should just hang down.




4. Close the plastic covers:

Close both plastic covers (E) ensuring you slide them shut.

Using the booster seat (continued)


WARNING! Only use the booster seat on an adult chair when the booster backrest is in an upright position (not reclined). The adult's chair should have a seat depth of more than 330mm, a width of more than 460mm and a backrest height greater than 300mm.



4. Attach the booster seat to a chair:

Ensure the backrest is in an upright position and that both booster straps have been pulled out from their storage spaces and correctly prepared as described on page 12.

Place the booster seat on a suitable adult chair. Wrap the two backrest straps (F) around the back of the chair (G) and fasten the buckle. Wrap the base straps (H) under the base of the chair (I) and fasten the buckle.




5. Tighten the seat straps:

With the straps fastened pull the backrest strap (J) to tighten both the backrest strap and base strap simultaneously. Once the straps are tight, tidy the end of the backrest strap away in the clip (K).

WARNING! Ensure the booster seat is firmly attached before putting your child in the seat.

After use

When not being used as a booster seat and not attached to an adult chair the booster straps **MUST** be stored in the storage spaces on either side of the seat.



1. Storing the booster straps:





(A) Push down slightly on the plastic covers and slide them backwards on each side of the booster seat to access the storage spaces.

(B) Remove the backrest straps from the slot.

(C) Coil up the straps and place them into the storage spaces on each side of the seat.

(D) Close the plastic covers ensuring you slide them shut.

After use (continued)



2. Folding the booster seat for transporting:

(E) Slightly pull both tabs on each side of the tray outwards to release the food tray.

(F) Lift the backrest upwards to release it.

(G) Fold the backrest forwards.

(H) Line up the tab holes on the tray with the mounting points on the seat. Push the tray down onto the mounting points, ensuring the tray clicks into place and that the tab holes on both sides of the tray are in the same position.

(I) Carry the folded booster seat using the hand grip in the backrest.



Customerservice@kooltrade.co.uk
Imported by MyChild. M34 3QA
www.mychild.co.uk
Tel: 0161 335 2508